



Tip

When do you use Plenum Cable?

In building construction the space used for air circulation (heating and air conditioning) is called the plenum. This space is also commonly used to route communications cable. This poses a serious hazard in the event of fire due to lack of barriers to contain the smoke and flames. This is why various fire codes and the National Electrical Code (NEC) require the use of fire resistant and low smoke producing cable in these areas. This type of cable is called plenum cable and is coated with a fire retardant coating to produce a cable that is fire resistant and has low smoke producing characteristics.