


Item #	Description	1-9	10-24	25-99	100-249	250-499
✓RoHS FME to BNC Interseries Coaxial Adapters - 50 and 75 Ohm - Useful in Cellular Applications						
Many cellular communication devices utilize the FME connector on coaxial antenna lines. L-com offers a selection of highest quality components utilizing machined brass with nickel plated surfaces and gold plated pins.						
BA8016	Coaxial Adapter, FME Male / BNC Female, 50 Ohm	4.95	4.65	4.36	4.06	3.76
BA8005	Coaxial Adapter, FME Male / BNC Male, 75 Ohm	3.95	3.71	3.48	3.24	3.00
BA8006	Coaxial Adapter, FME Male / 90° BNC Male, 75 Ohm	4.95	4.65	4.36	4.06	3.76
✓RoHS 1.6/5.6 to BNC Interseries Coaxial Adapters - 50 Ohm - For Conversion to the European Standard						
These machined adapters are great for converting standard BNC terminations to 1.6/5.6 terminations which are common in other areas of the world.						
BA9200	Coaxial Adapter, BNC Male / 1.6/5.6 Female Adapter	7.95	7.47	7.00	6.52	6.04
BA9201	Coaxial Adapter, BNC Female / 1.6/5.6 Male Adapter	7.95	7.47	7.00	6.52	6.04
✓RoHS Type F Interseries Coaxial Adapters - 50 Ohm						
BA120	Coaxial Adapter, Type F Male / BNC Female	1.95	1.83	1.72	1.60	1.48
BA121	Coaxial Adapter, Type F Male / TNC Male	1.95	1.83	1.72	1.60	1.48
BA125	Coaxial Adapter, Type F Female / BNC Male	1.95	1.83	1.72	1.60	1.48
BA127	Coaxial Adapter, Type F Female / TNC Female	1.95	1.83	1.72	1.60	1.48
BA220	Coaxial Adapter, Type F Female / BNC Female	1.95	1.83	1.72	1.60	1.48
✓RoHS RCA Interseries Coaxial Adapters - 50 and 75 Ohm						
BA90	Coaxial Adapter, RCA Male / BNC Female, 50 Ohm	2.95	2.77	2.60	2.42	2.24
BA94	Coaxial Adapter, RCA Female / BNC Female, 50 Ohm	2.95	2.77	2.60	2.42	2.24
BA95	Coaxial Adapter, RCA Female / BNC Male, 50 Ohm	2.95	2.77	2.60	2.42	2.24
BA887	Coaxial Adapter, RCA Female / Type F Female, 50 Ohm	1.95	1.83	1.72	1.60	1.48
BA907	Coaxial Adapter, RCA Male / Type F Female, 75 Ohm	1.95	1.83	1.72	1.60	1.48
✓RoHS Type N Interseries Coaxial Adapters - 50 Ohm						
BN107	Coaxial Adapter, Type N Male / BNC Male	5.75	5.40	5.06	4.72	4.37
BN109	Coaxial Adapter, Type N Male / BNC Female	5.75	5.40	5.06	4.72	4.37
AXA-NMSM	Coaxial Adapter, Type N Male / SMA Male	3.99	3.83	3.67	3.39	2.99
AXA-NMTF	Coaxial Adapter, Type N Male / TNC Female	3.99	3.83	3.67	3.39	2.99
AXA-NMFF	Coaxial Adapter, Type N Male / Type F Female	3.49	3.35	3.21	2.97	2.62
AXA-NMRSJ	Coaxial Adapter, Type N Male / RP-SMA Jack	4.99	4.79	4.59	4.24	3.74
AXA-NMRSJ	Coaxial Adapter, Type N Male / RP-SMA Plug	4.99	4.79	4.59	4.24	3.74
AXA-NMRTJ	Coaxial Adapter, Type N Male / RP-TNC Jack	4.99	4.79	4.59	4.24	3.74
AXA-NMRTJ	Coaxial Adapter, Type N Male / RP-TNC Plug	4.99	4.79	4.59	4.24	3.74
BN110	Coaxial Adapter, Type N Female / BNC Female	5.75	5.40	5.06	4.72	4.37
BN115	Coaxial Adapter, Type N Female / BNC Male	5.75	5.40	5.06	4.72	4.37
AXA-AMNFB	Coaxial Adapter, Type N Female Bulkhead / NMO	12.99	12.47	11.95	11.04	9.74
AXA-NFMUM	Coaxial Adapter, Type N Female / Mini-UHF Male	3.49	3.35	3.21	2.97	2.62
AXA-NFTM	Coaxial Adapter, Type N Female / TNC Male	3.49	3.35	3.21	2.97	2.62
AXA-NFRBP	Coaxial Adapter, Type N Female / RP BNC Plug	3.49	3.35	3.21	2.97	2.62
AXA-NFRSJ	Coaxial Adapter, Type N Female / RP-SMA Jack	4.99	4.79	4.59	4.24	3.74
AXA-RSJNFB	Coaxial Adapter, Type N Female Bulkhead / RP-SMA Jack	5.75	5.52	5.29	4.89	4.31
AXA-NFRSP	Coaxial Adapter, Type N Female / RP-SMA Plug	3.99	3.83	3.67	3.39	2.99
AXA-NFRTP	Coaxial Adapter, Type N Female / RP-TNC Plug	4.99	4.79	4.59	4.24	3.74
AXA-NFRTP2	Coaxial Adapter, Type N Female / RP-TNC Plug 1 Piece Design	4.99	4.79	4.59	4.24	3.74
✓RoHS Mini-UHF Interseries Coaxial Adapters - 50 Ohm						
BA881	Coaxial Adapter, Mini-UHF Female / TNC Male	5.75	5.40	5.06	4.72	4.37
BA882	Coaxial Adapter, Mini-UHF Female / BNC Male	5.75	5.40	5.06	4.72	4.37
BA883	Coaxial Adapter, Mini-UHF Male / BNC Female	5.75	5.40	5.06	4.72	4.37
BA886	Coaxial Adapter, Mini-UHF Male / TNC Female	5.75	5.40	5.06	4.72	4.37
✓RoHS UHF Interseries Coaxial Adapters - 50 Ohm						
BA40	Coaxial Adapter, UHF Male / RCA Female	2.95	2.77	2.60	2.42	2.24
BA130	Coaxial Adapter, UHF Female / Type F Male	2.95	2.77	2.60	2.42	2.24
BA140	Coaxial Adapter, UHF Female / RCA Male	2.95	2.77	2.60	2.42	2.24
BA160	Coaxial Adapter, UHF Male / Type F Female	2.95	2.77	2.60	2.42	2.24
BA230	Coaxial Adapter, UHF Female / BNC Female	3.95	3.71	3.48	3.24	3.00
BA270	Coaxial Adapter, UHF Male / BNC Male	2.95	2.77	2.60	2.42	2.24
BA301	Coaxial Adapter, UHF Female / Type F Female	2.95	2.77	2.60	2.42	2.24
✓RoHS TNC Interseries Coaxial Adapters - 50 Ohm						
AXA-RTJRSJ	Coaxial Adapter, RP-TNC Jack / RP-SMA Plug	3.99	3.83	3.67	3.39	2.99
AXA-RTPRSJ	Coaxial Adapter, RP-TNC Plug / RP-SMA Jack	3.99	3.83	3.67	3.39	2.99



Free access to over 3,000 CAD models
 Download CAD models and 2D drawings for integrating into your projects. L-com.com/CadDemo

