



Using the TL-N044-000-R for checking premise wiring



Patch
Cord

Patch Panel



Master unit sends signal through premise wiring.
LEDs light as it steps through each conductor.

Horizontal Runs

Unshielded
or Shielded
Twisted Pair

Wall Plate



Patch Cord



Remote Unit LEDs
light up as it receives
signal through
each conductor.