



## *Using the DXB66 for checking premise wiring*



Remote unit sends signal through premise wiring

Patch Cord

Patch Panel



Horizontal Runs

Unshielded  
or Shielded  
Twisted Pair

Wall Plate



Patch Cord



Master unit displays results